

# **Platinum Solo Whistle Digital Servo Drive Installation Guide**

**Functional Safety**  
**Safety Capability: F, S, O**  
**EtherCAT and CANopen**



April 2024 (Ver. 3.002)

This guide is delivered subject to the following conditions and restrictions:

- This guide contains proprietary information belonging to Elmo Motion Control Ltd. Such information is supplied solely for the purpose of assisting users of Elmo's servo drive(s) in their installation.
- The text and graphics included in this manual are for the purpose of illustration and reference only. The specifications on which they are based are subject to change without notice.
- Elmo Motion Control and the Elmo Motion Control logo are trademarks of Elmo Motion Control Ltd.
- Information in this document is subject to change without notice.



Elmo Motion Control and the Elmo Motion Control logo are registered trademarks of Elmo Motion Control Ltd.



EtherCAT® and Safety over EtherCAT® are registered trademarks and patented technologies, licensed by Beckhoff Automation GmbH, Germany.



EtherCAT® Conformance tested is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.



CANopen compliant. CANopen® is a registered trademark and patented technology, licensed by CAN in Automation (CiA) GmbH, Kontumazgarten 3, DE-90429 Nuremberg, Germany.

Document no. MAN-P-SOLWHI\_IG-EC (Ver. 3.002)

Copyright © 2024

Elmo Motion Control Ltd.


All rights reserved.

## Revision History

Version	Date	Version	Date	Update
Ver. 2.000	June 2020	Ver. 2.011	Mar 2022	
Ver. 2.001	July 2020	Ver. 2.012	Mar 2022	
Ver. 2.002	Aug 2020	Ver. 2.013	May 2022	
Ver. 2.003	Aug 2020	Ver. 2.014	May 2022	
Ver. 2.004	Aug 2020	Ver. 2.015	Jan 2023	
Ver. 2.005	Oct 2020	Ver. 2.016	Feb 2023	
Ver. 2.006	Dec 2020	Ver. 2.017	Apr 2023	
Ver. 2.007	Aug 2021	Ver. 2.018	Aug 2023	
Ver. 2.008	Oct 2021	Ver. 3.000	Dec 2023	Updated photo on front page, kW of power in chapter 4, Cable Kit number in section 4.1. Drawings in sections 7.2, 7.11, and 7.16
Ver. 2.009	Dec 2021	Ver. 3.001	Dec 2023	Updated sections 5.4.6 and 5.4.7 to “Digital Input” and “Digital Output and Current”
Ver. 2.010	Dec 2021	Ver. 3.002	Apr 2024	Small change to heading of section 8.6.1.3 Hiperface

# Catalog Number

PWHI-Sz-zXXX/YYYzzzQ



## Cable Kit

The following cable kits may be ordered:

Catalog numbers: CBL-PSOLWHIKIT01 - EtherCAT and CBL-PSOLWHIKIT02 - CAN Cable kits

For further details, see the MAN-P-SOLWHIBEL-CBLKIT cable kit manual.

<b>Chapter 1:</b>	<b>This Installation Guide.....</b>	<b>9</b>
<b>Chapter 2:</b>	<b>Functional Safety .....</b>	<b>9</b>
<b>Chapter 3:</b>	<b>Safety Information .....</b>	<b>9</b>
3.1	Warnings.....	10
3.2	Cautions.....	10
3.3	CE Marking Conformance .....	10
3.4	Warranty Information .....	10
<b>Chapter 4:</b>	<b>Product Description .....</b>	<b>11</b>
4.1	Accessories .....	11
<b>Chapter 5:</b>	<b>Technical Information .....</b>	<b>12</b>
5.1	Physical Specification.....	12
5.2	Technical Data .....	12
5.2.1	100V Models .....	12
5.2.2	200V Models .....	13
5.3	Control Supply .....	13
5.4	Product Features .....	14
5.4.1	Feedback .....	14
5.4.2	Encoder Supply.....	14
5.4.3	Communication .....	14
5.4.4	Analog Input.....	14
5.4.5	STO .....	14
5.4.6	Digital Input.....	15
5.4.7	Digital Output and Current.....	15
5.5	Environmental Conditions .....	16
5.6	Certifications and Standards.....	17
5.6.1	Functional Safety.....	17
5.6.2	Electrical Safety .....	17
5.6.3	Electromagnetic Compatibility .....	17
5.6.4	Environmental .....	18
5.6.5	Other Compliant Standards.....	18
5.6.6	Dual Use .....	18
<b>Chapter 6:</b>	<b>Installation.....</b>	<b>19</b>
6.1	Unpacking the Drive Components.....	19
6.2	Over-Current and Short-Circuit Protection.....	19
6.3	Mounting the Platinum Solo Whistle .....	20
<b>Chapter 7:</b>	<b>Connector Types, Pinouts, and LEDs .....</b>	<b>21</b>
7.1	Mating Connector.....	21

7.2	Connector Locations .....	22
7.3	Solo Board Indicator Labelling .....	23
7.4	Motor Power Connector Pinouts (M1).....	23
7.5	Main Power Connector Pinouts (P1) .....	24
7.6	Control Power Supply Connector Pinouts (P2) .....	24
7.7	Drive Status Indicator .....	25
7.8	STO (Safe Torque Off) Connector Pinouts (J4).....	25
7.9	Port A and Port B and Power Connector Pinouts (J1).....	26
7.9.1	J1 Port A .....	26
7.9.2	J1 Port B.....	26
7.9.3	J1 Hall Sensors .....	26
7.9.4	J1 Power Pins.....	27
7.10	Port C Connector Pinouts (J2).....	28
7.11	Digital I/Os Connector Pinouts (J3).....	29
7.11.1	Safe IO: IO TYPE = K, L, N .....	29
7.11.2	Regular IO: IO TYPE = U, V .....	30
7.12	USB 2.0 Connector Pinouts (X3) .....	31
7.13	RS-232 and Differential RS-232 (RS-422) Serial Communication(X4) .....	32
7.14	EtherCAT IN Connector Pinouts (X1) .....	33
7.15	EtherCAT OUT/Ethernet Connector Pinouts (X2).....	34
7.16	CAN Connector Pinouts (X1, X2) Safety Capability: O Only .....	35
<b>Chapter 8:</b>	<b>Wiring.....</b>	<b>36</b>
8.1	Wiring Connectors .....	37
8.1.1	Wiring Female CON CLIK-MATE Connectors .....	37
8.2	The Platinum Solo Whistle Connection Diagrams .....	38
8.2.1	EtherCAT with Safe IO (For Safety Capability F) .....	38
8.2.2	EtherCAT with Regular IO (Safety Capability: S, O) .....	39
8.2.3	CAN, RS-232, RS-422 (Safety Capability: O).....	40
8.3	Motor Power (M1).....	41
8.4	Main (P1) and Control Power (P2).....	42
8.4.1	Main Supply.....	42
8.4.2	Control Supply .....	42
8.4.3	Dual Power Supply .....	43
8.4.4	Dual Power Supply for Safety Configuration .....	44
8.5	STO (Safe Torque Off) (J4) .....	45
8.5.1	Source Mode – PLC Voltage Level .....	45
8.5.2	TTL Mode – TTL Voltage Level .....	45
8.6	Feedbacks (J1 and J2) .....	46
8.6.1	Feedback Port A .....	46

8.6.1.1	Incremental Encoder .....	46
8.6.1.2	Absolute Serial Encoder .....	47
8.6.1.3	Hiperface .....	48
8.6.2	Feedback Port B .....	49
8.6.2.1	Incremental Encoder .....	49
8.6.2.2	Interpolated Analog (Sine/Cosine) Encoder .....	50
8.6.2.3	Resolver .....	50
8.6.3	Feedback Port C.....	51
8.6.3.1	Incremental Encoder .....	51
8.6.3.2	Absolute Serial Encoder .....	52
8.6.3.3	Emulated Encoder Output .....	53
8.6.4	Feedback - Hall Sensors.....	53
8.7	Safe Digital I/Os (Safe IO Type: K, L, N) (J3) .....	54
8.7.1	Digital Input with Test Pulse.....	54
8.7.2	OSSD Digital Input .....	54
8.7.3	Digital Output.....	55
8.7.3.1	Option K Configuration VDD_24 .....	55
8.7.3.2	Option L Configuration VDD_24 & VDD_48.....	56
8.7.3.3	Option N Configuration VDD_48 .....	56
8.8	Regular Digital I/Os (Safe IO Type: U, V) (J3) .....	57
8.8.1	Digital Input and Output 5V Logic (IO Type: U) .....	57
8.8.2	Digital IO PLC Source and Sink Mode (IO Type: V) .....	58
8.8.2.1	Digital Input and Output PLC Source Mode.....	58
8.8.2.2	Digital Input and Output PLC Sink Mode .....	59
8.9	Analog Input .....	60
8.9.1	Analog Input1 -Differential (J2) .....	60
8.10	Communication .....	61
8.10.1	USB 2.0 (X3).....	61
8.10.2	Serial Communication (X4).....	61
8.10.2.1	RS-422 (Differential RS-232) Serial Communication.....	61
8.10.2.2	RS-232 Serial Communication .....	62
8.10.3	EtherCAT (X1 and X2) .....	63
8.10.3.1	EtherCAT Connection.....	63
8.10.3.2	EtherCAT Status Indicator.....	63
8.10.3.3	EtherCAT Link Indicators.....	64
8.10.3.4	EtherCAT Address Switches .....	64
8.11	CANopen (X1 and X2) .....	65
8.11.1	CAN Wiring .....	65

<b>Chapter 9: Powering Up .....</b>	<b>66</b>
9.1 Initializing the System.....	66
9.2 Heat Dissipation.....	66
9.2.1 Thermal Data.....	66
9.2.2 Heat Dissipation Data.....	66
9.2.3 How to Use the Charts .....	67
<b>Chapter 10: Dimensions .....</b>	<b>68</b>
10.1 EtherCAT.....	68
10.1.1 PWHI-SF-XXX/YYYYFzz .....	68
10.1.2 PWHI-SS-XXX/YYYYFzz or PWHI-SO-XXX/YYYYFzz .....	68
10.2 CAN .....	69
10.2.1 PWHI-SO-XXX/YYYSzz or PWHI-SO-XXX/YYYYTzz .....	69

## Chapter 1: This Installation Guide

This installation Guide details the technical data, pinouts, and power connectivity of the Platinum Solo Whistle.

**For a comprehensive specification and detailed description of the functions, refer to the Platinum Safety Drive.**

## Chapter 2: Functional Safety

The Platinum Solo WHI drives support Functional Safety. It is necessary to implement the instructions in the Platinum Safety Drive Manual regarding using STO, Feedbacks, IOs and Power supplies with Functional Safety.

## Chapter 3: Safety Information

In order to achieve the optimum, safe operation of the Platinum Solo Whistle, it is imperative that you implement the safety procedures included in this installation guide. This information is provided to protect you and to keep your work area safe when operating the Platinum Solo Whistle and accompanying equipment.

**Please read this chapter carefully before you begin the installation process.**

Before you start, ensure that all system components are connected to earth ground. Electrical safety is provided through a low-resistance earth connection.

Only qualified personnel may install, adjust, maintain and repair the servo drive. A qualified person has the knowledge and authorization to perform tasks such as transporting, assembling, installing, commissioning and operating motors.

The Platinum Solo Whistle contains electrostatic-sensitive components that can be damaged if handled incorrectly. To prevent any electrostatic damage, avoid contact with highly insulating materials, such as plastic film and synthetic fabrics. Place the product on a conductive surface and ground yourself in order to discharge any possible static electricity build-up.

To avoid any potential hazards that may cause severe personal injury or damage to the product during operation, keep all covers and cabinet doors shut.

The following safety symbols are used in this and all Elmo Motion Control manuals:



**Warning:**

This information is needed to avoid a safety hazard, which might cause bodily injury or death as a result of incorrect operation.



**Hot Surface Warning:**

To alert against surfaces that may reach high temperatures. The heatsink and wires may reach high temperatures.



**Caution:**

This information is necessary to prevent bodily injury, damage to the product or to other equipment.



**Important:**

Identifies information that is critical for successful application and understanding of the product.

The following symbols are used in this document:



**Note:** Information critical to the understanding and/or operating the feature.



**Tip:** Information that helps understanding a feature, is good practice or a possible different way of action.

### 3.1 Warnings

- To avoid electric arcing and hazards to personnel and electrical contacts, never connect/disconnect the servo drive while the power source is on.
- Power cables can carry a high voltage, even when the motor is not in motion. Disconnect the Platinum Solo Whistle from all voltage sources before servicing.
- The high voltage products within the Platinum Line range contain grounding conduits for electric current protection. Any disruption to these conduits may cause the instrument to become hot (live) and dangerous.
- STO, Safe I/O (Safety Capability "F") and EtherCAT (Safety Capability "F", "S") circuits are separated from power circuits by reinforced insulation and can be supplied by SELV power supply. Other Control and communication level circuits are separated from power circuits by functional insulation. These circuits shall have insulation to their surroundings and other control or communication circuits based on the Working Voltage and requirements of the end use application.



#### Capacitance Discharge

After shutting off the power and removing the power source from your equipment, wait at least 10 seconds before touching or disconnecting parts of the equipment that are normally loaded with electrical charges (such as capacitors or contacts). Measuring the electrical contact points with a meter, before touching the equipment, is recommended.

### 3.2 Cautions

- The maximum DC power supply connected to the instrument DC must comply with the parameters outlined in this guide.
- When connecting the Platinum Solo Whistle to an approved isolated Control power supply, connect it through a line that is separated from hazardous live voltages using reinforced or double insulation in accordance with approved safety standards.
- Before switching on the Platinum Solo Whistle, verify that all safety precautions have been observed and that the installation procedures in this manual have been followed.
- Make sure that the Safe Torque Off is operational.

### 3.3 CE Marking Conformance

The Platinum Solo Whistle is intended for incorporation in a machine or end product. The actual end product must comply with all safety aspects of the relevant requirements of the European Safety of Machinery Directive 2006/42/EC as amended, and with those of the most recent versions of standards EN 60204-1 and EN ISO 12100 at the least, and in accordance with 2006/95/EC.

Concerning electrical equipment designed for use within certain voltage limits, the Platinum Solo Whistle meets the provisions outlined in 2006/95/EC. The party responsible for ensuring that the equipment meets the limits required by EMC regulations is the manufacturer of the end product.

### 3.4 Warranty Information

The products covered in this manual are warranted to be free of defects in material and workmanship and conform to the specifications stated either within this document or in the product catalog description. All Elmo drives are warranted for a period of 12 months from the time of installation, or 12 months from time of shipment, whichever comes first. No other warranties expressed or implied — and including a warranty of merchantability and fitness for a particular purpose — extend beyond this warranty.

## Chapter 4: Product Description

The Platinum Solo Whistle is an integrated solution delivering up to **2 kW of continuous power** or **4 kW of peak power** in a compact package (66.0 x 46.5 x 37.0 mm (2.60" x 1.83" x 1.46") for the Safe IO version and 66.0 x 46.5 x 34.6 mm (2.60" x 1.83" x 1.36") for the Regular IO version), and designed to simply and efficiently connect Elmo's Platinum Solo Whistle servo drive directly to the application. The solution consists of the Platinum Solo Whistle together with a convenient connection interface, which either eliminates or reduces development time and resources when designing an application's PCB board.

This advanced high power density servo drive provides top performance, Functional Safety, advanced networking as well as a fully featured motion controller and local intelligence.

The Platinum Solo Whistle is provided in three safety configurations:

- **Functional Safety with Safe IO (PWHI-zF):** Servo drive with Function Safety and Safe IO – This configuration of Servo drives includes safe Digital IO which support Safe Digital Inputs and Outputs including Brakes. This configuration supports the operation of the safety function either via FSOE or via the Safe I/O.
- **Functional Safety with regular IO (PWHI-zS):** Servo drive with Function Safety excluding Safe IO – This configuration of Servo drives includes regular Digital IO. This configuration permits operation of safety functions only via FSOE (Fail Safe Over EtherCAT).
- **STO Only (PWHI-zO (SIL3,Plc,CAT3)):** Servo drive with STO – The servo drive supports only STO

The Platinum Solo Whistle is powered by dual isolated power supplies from the Main, main DC power 10 V to 195 V and a Control power supply for the logic.

The drive can operate as a stand-alone device or as part of a multi-axis system in a distributed configuration on a real-time network.

The Platinum Solo Whistle drive is easily set up and tuned using Elmo Application Studio (EASII) software tools. As part of the Platinum product line, it is fully programmable with the Elmo motion control language. For more about software tools refer to the Elmo Application Studio Inline-Help.

### 4.1 Accessories

The following cable kits may be ordered:

Catalog numbers:

- CBL-PSOLWHIKIT01 - EtherCAT Cable Kit
- CBL-PSOLWHIKIT02 - CAN Cable Kit

For further details, see the MAN-P-SOLWHIBEL-CBLKIT cable kit manual.

## Chapter 5: Technical Information

### 5.1 Physical Specification

Feature	Units	All Types
Weight	g (oz.)	~100 g (3.53 oz)
Weight with Safe IO Board	g (oz.)	~110 g (3.88 oz)
CAN and Regular Digital IO EtherCAT Version Dimensions	mm (in)	66.0 x 46.5 x 34.6 mm (2.60" x 1.83" x 1.36")
EtherCAT with Safe IO Version Dimensions	mm (in)	66.0 x 46.5 x 37.0 mm (2.60" x 1.83" x 1.46")
Mounting method		Panel Mounted
Degrees of protection		IP=00

### 5.2 Technical Data

#### 5.2.1 100V Models

Feature	Units	1/100	2.5/100	5/100	10/100	15/100	20/100	25/100
Minimum supply voltage	VDC	10						
Nominal supply voltage	VDC	85						
Maximum supply voltage	VDC	95						
Maximum continuous power output	W	80	200	400	800	1200	1600	2000
Efficiency at rated power (at nominal conditions)	%	> 99						
Maximum output voltage		Up to 95% of DC bus voltage						
Amplitude sinusoidal/DC continuous current	A	1.0	2.5	5	10	15	20	25
Sinusoidal continuous RMS current limit (Ic)	A	0.7	1.8	3.5	7	10.6	14.1	17.5
Peak current limit	A	2 x Ic						

Table 1: Technical Data



**Note (on current ratings):**

The current ratings of the Platinum Solo Whistle are given in units of DC amperes (ratings that are used for trapezoidal commutation or DC motors). The RMS (sinusoidal commutation) value is the DC value divided by 1.41.

### 5.2.2 200V Models

Elmo now offers a 200 VDC maximum output rating selection of Platinum Solo Whistle, according to the following technical data:

Feature	Units	3/200	6/200	9/200
Minimum supply voltage	VDC	20		
Nominal supply voltage	VDC	170		
Maximum supply voltage	VDC	195		
Maximum continuous power output	W	480	960	1450
Efficiency at rated power (at nominal conditions)	%	> 99		
Maximum output voltage		Up to 95% of DC bus voltage		
Amplitude sinusoidal/DC continuous current	A	3	6	9
Sinusoidal continuous RMS current limit (Ic)	A	2.1	4.2	6.3
Peak current limit	A	2 x Ic		

### 5.3 Control Supply

Feature		Units	Details
Control supply for input voltage where the Safety Capability is F, S		V	<b>Isolated DC source:</b> 12 to 60
Control supply for input voltage where the Safety Capability is O		V	<b>Isolated DC Source:</b> 12 to 95
24V Control supply input power consumption	Without encoder	W	≤4
	With encoder up to 400mA@5V	W	≤6
	<b>For Safety Capability F only</b> With encoder up to 300mA@11V	W	≤7

## 5.4 Product Features

### 5.4.1 Feedback

Feature	Details	Presence and No.
Feedback	Standard Port A, B, & C	√

### 5.4.2 Encoder Supply

Feature	Details
5V supply	5V Nominal, 4.75V÷5.25V up to 400mA
11V supply only with Safety Capability: F	11V Nominal, 10.6V÷11.5V up to 300mA

### 5.4.3 Communication

Feature	Details	Presence and No.	
Communication Options	USB	√	
	EtherCAT <i>or</i>	√	
	CAN	√	
	RS-232 <i>or</i>	√	Available only for network S or T
	RS-422 (Differential RS-232)	√	

### 5.4.4 Analog Input

Feature	Details	Resolution	Presence and No.
Analog Input	Differential ±10V	14-bits	1
	Single Ended	12-bits	1

### 5.4.5 STO

Feature	Details	Presence and No.
STO	5V Logic, Opto Isolated, for IO TYPE = U	√
	PLC source, Opto Isolated, for IO TYPE = K, L, N, V	

### 5.4.6 Digital Input

I/O Style	Safe Input	U	V
Safety/Regular	PLC Source Isolated	Regular IO 5V Logic	Regular IO PLC Source or Sink
Input	IN1, IN2, IN3, IN4	IN1, IN2, IN3, IN4, IN5, IN6	

### 5.4.7 Digital Output and Current

Refer to the Safety Capability in the P/N for the relevant IO capability.

I/O Style	K	L	N	U	V
Safety/Regular	Safe IO	Safe IO	Safe IO	Regular IO	Regular IO
Voltage	24V – All IOs	24V – OUT1,2,3,4 48V – OUT7,8	48V – OUT7,8	5V Logic	PLC
VDD VDD_24 VDD_48	19.6 to 30V	19.6 to 30V 19.6 to 60V	19.6 to 60V	4 to 30V	19.6 to 30V
OUT1	250mA	250mA	N/A	15mA	1000mA
OUT2	250mA	250mA	N/A	15mA	1000mA
OUT3	250mA	250mA	N/A	N/A	N/A
OUT4	250mA	250mA	N/A	N/A	N/A
OUT7	1000mA	1000mA	1000mA	15mA	1000mA
OUT8 (PLC SINK)	1000mA	1000mA	1000mA	15mA	1000mA
Total Current <sup>1</sup>	1500mA	1500mA	1500mA		1250mA

<sup>11</sup> **NOTE:** The total output current of the six digital outputs must not exceed the values shown in this table.

## 5.5 Environmental Conditions

You can guarantee the safe operation of the Platinum Solo Whistle by ensuring that it is installed in an appropriate environment. The Functional Safety of the servo drive is certified according to the environmental conditions in the following table.

Feature	Details
<b>Operating ambient temperature</b>	0 °C to 55 °C (32 °F to 131 °F)  <b>Remark:</b> Functional Safety is applicable to the above operating temperature.
<b>Storage temperature</b>	-40 °C to +85 °C ( -40 °F to +185 °F)
<b>Maximum non-condensing humidity according to IEC60068-2-78</b>	95%
<b>Maximum Operating Altitude</b>	2,000 m (6562 feet) It should be noted that servo drives capable of higher operating altitudes are available on request.
<b>Mechanical Shock according to IEC60068-2-27</b>	15g / 11ms Half Sine
<b>Vibration according to IEC60068-2-6</b>	5 Hz ≤ f ≤ 10 Hz: ±10mm 10 Hz ≤ f ≤ 57 Hz: 4G 57 Hz ≤ f ≤ 500 Hz:5G
<b>Pollution Degree</b>	Pollution Degree 2

## 5.6 Certifications and Standards

The following table describes the Main Standards of the Platinum Solo Whistle servo drive. For further details, refer to Chapter 22 in the [Platinum Safety Drive Manual](#).

### 5.6.1 Functional Safety

Standard	Item
IEC 61800-5-2:2017	Adjustable speed electrical power drive systems – Safety requirements – Functional
EN ISO 13849-1:2015	Safety of machinery — Safety-related parts of control systems.
EN 61508-1:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems
EN 61508-2:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems
EN 61508-3:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems
IEC 61784-3:2016	Functional Safety Filed Bus - FSOE

### 5.6.2 Electrical Safety

Specification	Details
IEC/EN 61800-5-1:2007	Adjustable speed electrical power drive systems Part 5-1: Safety requirements – Electrical, thermal and energy
In compliance with UL 61800-5-1	Adjustable speed electrical power drive systems: Safety requirements – Electrical, thermal and energy
In compliance with CSA C22.2 NO. 274-17	Adjustable speed drives

### 5.6.3 Electromagnetic Compatibility

Specification	Details
EN 61800-3:2004/A1:2011	Adjustable speed electrical power drive systems Part 3: EMC requirements and specific test methods
EN 61800-5-2: 2017 Annex E	Adjustable speed electrical power drive systems Part 5-2: Safety requirements – Functional

### 5.6.4 Environmental

Specification	Details
IEC60068-2-78	Damp heat, steady state
IEC60068-2-6	Vibration (sinusoidal)
IEC60068-2-2	Dry heat
IEC60068-2-27	Shock
IEC60068-2-1	Cold Test

### 5.6.5 Other Compliant Standards

For other compliant standards refer to the

[Platinum Safety Drive Manual Section 22.5](#) or refer to the Elmo website:

<https://www.elmomc.com/capabilities/standards-compliance/platinum-family/>

### 5.6.6 Dual Use

No export license is required for the Platinum Line products signified with the suffix Q in the Part Number.

The operating frequency of the Platinum Line products is “factory limited” to  $\leq 599$  Hz, and therefore complies with the EU Dual Use Regulation 428/2009, 3A225, and the US Dual Use regulation EAR ECCN# 3A225.

This statement applies to all identical specimens and will become invalid if a change is made in the firmware.

## Chapter 6: Installation

The Platinum Solo Whistle must be installed in a suitable environment and be properly connected to its voltage supplies and the motor.

### 6.1 Unpacking the Drive Components

Before you begin working with the Platinum Solo Whistle, verify that you have all of its components, as follows:

- The Platinum Solo Whistle servo drive
- The Elmo Application Studio (EASII) software

The Platinum Solo Whistle is shipped in a cardboard box with Styrofoam protection.

#### To unpack the Platinum Solo Whistle:

1. Carefully remove the servo drive from the box and the Styrofoam.
2. Check the drive to ensure that there is no visible damage to the instrument. If any damage has occurred, report it immediately to the carrier that delivered your drive.
3. To ensure that the Platinum Solo Whistle you have unpacked is the appropriate type for your requirements, locate the part number sticker on the side of the Platinum Solo Whistle. It looks like this:



4. Verify that the Platinum Solo Whistle type is the one that you ordered, and ensure that the voltage meets your specific requirements.

The part number at the top provides the type designation. Refer to the appropriate part number in the section Catalog Number at the beginning of the installation guide.

### 6.2 Over-Current and Short-Circuit Protection

A serial fuse or circuit breaker should be installed Rated for drive's continuous current rating.

PWHI-zz-zXXX/YYYzzz-z XXX = rated continues current [A]	Fuse	Circuit Breaker
1, 2.5, 5, 10, 15, 20, 25 / 100v	Fast Acting	Type B
3, 6, 9, 10 / 200v	Fast Acting	
Rated short - circuit breaking capacity 5kA		

#### PL/CL protection: Peak and Continues Limitation

The peak current of servo drive limit for a given application is programmed to the parameter **PL[1]** amperes.

**PL[1]**: Value for peak current limit protection. Please refer to the "Platinum Administrative Guide".

### 6.3 Mounting the Platinum Solo Whistle

The Platinum Solo Whistle was designed for mounting on a surface. When integrating the Platinum Solo Whistle into a device, be sure to leave about 1 cm (0.4") outward from the heat-sink to enable free air convection around the drive. If the Platinum Solo Whistle is enclosed in a metal chassis, we recommend that the Platinum Solo Whistle be screw-mounted to it to help with heat dissipation. The Platinum Solo Whistle has screw-mount holes on each corner of the heat-sink for this purpose – see below.




Figure 1: Mounting the Platinum Solo Whistle

When the Platinum Solo Whistle is not connected to a metal chassis, the application’s thermal profile may require a solution for heat dissipation due to insufficient air convection. In this case, we recommend that you connect an external heat-sink. Elmo has an external heat-sink (Catalog number: WHI-HEATSINK-2) that can be ordered for this purpose – see below.




Figure 2: Platinum Solo Whistle External Heat-sink

## Chapter 7: Connector Types, Pinouts, and LEDs

The Platinum Solo Whistle has eleven connectors.

Port	No. Pins	Type	Function
<b>M1</b> M1, M2, M3, PE	4	Phoenix: CON TH TB Straight, 3.5mm pitch. Conductor cross-section is 26 up to 16 AWG	Motor phases
<b>P1</b> VP+, PR, PE	3	Phoenix: CON TH TB Straight, 3.5mm pitch. Conductor cross-section is 26 up to 16 AWG	Power
<b>P2</b> PR, VL	2	Phoenix: CON TH TB Straight, 3.5mm pitch. Conductor cross-section is 26 up to 16 AWG	Control Power
J1	2x10	Molex CLIK-Mate, 20 pins, 1.5mm pitch	Feedback Port A/B
J2	2x6	Molex CLIK-Mate, 12 pins, 1.5mm pitch	Feedback Port C
J3	2x7	Molex CLIK-Mate, 14 pins, 1.5mm pitch	I/O
X3	24	USB Type C	USB
X4	5	Molex Pico-Clasp™ 5 pins, 1.00mm pitch	RS-422/RS-232 communication (only available for Safety Cap.: <b>O</b> )
J4	1x3	Molex CLIK-Mate, 3 pins, 1.5mm pitch	STO
<b>EtherCAT Version</b>			
X1	1x5	Molex, CLIK-Mate, 5 pins, 1.5 mm pitch	EtherCAT IN
X2	1x5	Molex, CLIK-Mate, 5 pins, 1.5 mm pitch	EtherCAT OUT
<b>CAN Version</b>			
X1	1x5	Molex, CLIK-Mate, 5 pins, 1.5 mm pitch	CAN
X2	1x5	Molex, CLIK-Mate, 5 pins, 1.5 mm pitch	CAN

### 7.1 Mating Connector

Connector	Mating Connector Type	Mating Crimping Pins
J1 Feedback Port A/B	CON CLIK-MATE HOUSING FE 20PIN (2X10) P=1.5 mm pitch plug	MOLEX CRIMP TERMINAL FE 24-28AWG FOR CLIK-MATE 1.5 mm
J2 Feedback Port C	CON CLIK-MATE HOUSING FE 12PIN(2X6) P=1.5 mm pitch plug	
J3 I/O	CON CLIK-MATE HOUSING FE 14PIN(2X7) P=1.5 mm pitch plug	
J4 STO	CON CLIK-MATE HOUSING FE 3PIN(1X3) P=1.5 mm pitch plug	
X1, X2 EtherCAT IN/OUT or CAN Communication	CON CLIK-MATE HOUSING FE 5PIN(1X5) P=1.5 mm pitch plug	
X4 RS-422/RS-232 communication	CON Pico-Clasp™ HOUSING FE 5PIN (1X5) P=1 mm pitch	MOLEX CRIMP TERMINAL FE 28-32AWG FOR Pico-Clasp 1.0 mm
X3	Standard USB type C cable	

## 7.2 Connector Locations




Table 2: Connector Types

The pinouts in Chapter 8: Wiring describe the function of each pin in the Platinum Solo Whistle connectors that are listed in Table 2.

### 7.3 Solo Board Indicator Labelling

The following diagram describes the board indicator labelling for the Platinum Solo Whistle.




Figure 5: Platinum Solo Whistle Board Indicator Labelling

### 7.4 Motor Power Connector Pinouts (M1)

For further details, refer to [Chapter 10 Input Power Supply](#) in the [Platinum Safety Drive Manual](#).

Pin (M1) Signal		Function	Cable – Wires
		Brushless Motor	Brushed DC Motor
PE	Protective earth	Motor	Motor
M1	Motor phase	Motor	Not connected
M2	Motor phase	Motor	Motor
M3	Motor phase	Motor	Motor

#### Pin Positions





Table 3: Motor Connections

## 7.5 Main Power Connector Pinouts (P1)

Pin (P1) Signal	Function	Cable
PE	Protective Earth	DC Power
PR	Power Return	DC Power
VP+	Positive Power Input	DC Power

**Pin Positions**




P-SOLWHI-V2-SAFE-006A-B

Table 4: Main Power Connections

## 7.6 Control Power Supply Connector Pinouts (P2)

Pin (P2)	Signal	Function
1	PR	Control Supply Return
2	VL+	Control Supply Input

**Pin Positions**



P-SOLWHI-V2-SAFE-006A-C

Table 5: Control Supply Connections

## 7.7 Drive Status Indicator

Figure 6 shows the position of the red/green dual LED, which is used for immediate indication of the Initiation and Working states.




Figure 6: Status Indicator

The red/green dual LED is used for immediate indication of the following states:

- **Initiation state:** In this state, the LED indicates whether, the drive is in the boot state (blinking red) or in the operational state (steady red).
- **Working state:** In this state, the LED indicates whether the drive is in an amplifier failure state (red) or is ready to enable the motor (green).

## 7.8 STO (Safe Torque Off) Connector Pinouts (J4)

For further details, refer to the Chapter 12 STO in the [MAN-P Safety Drive Manual](#).

Pin (J4)	Signal	Function
1	STO1	STO 1 input
2	STO2	STO 2 input
3	STO_RET	STO signal return

Pin Positions	Cable Connector
	<p>CLIK-MATE FE ST 3PIN(1x3) P=1.5MM</p>

Table 6: STO Pin Assignments

## 7.9 Port A and Port B and Power Connector Pinouts (J1)

For full details, refer to [Chapter 13 Feedback](#) in the [MAN-P Safety Drive Manual](#).

### 7.9.1 J1 Port A

Pin (J1) Port A		Incremental Encoder	Absolute Serial Encoder
	Signal	Function	Function
5	PortA_A+	Channel A +	Absolute encoder clock+
7	PortA_A-	Channel A -	Absolute encoder clock-
9	PortA_B+	Channel B+	Absolute encoder data+
11	PortA_B-	Channel B -	Absolute encoder data -
13	PortA_Index+	Channel_Index+	
15	PortA_Index-	Channel_Index-	

Table 7: J1 Port A Pin Assignments

### 7.9.2 J1 Port B

Pin (J1) Port B		Incremental Encoder	Interpolated Analog Encoder	Resolver
	Signal	Function	Function	Function
		PWHI-SX-XXX/YYYYEX		PWHI-SX-XXX/YYYYERX
6	PortB_A+	Channel A+	Sine+	Sine+
8	PortB_A-	Channel A -	Sine-	Sine-
10	PortB_B+	Channel B+	Cosine+	Cosine+
12	PortB_B-	Channel B-	Cosine-	Cosine-
14	PortB_INDEX+	Channel_Index+	Analog_Index+	RESOLVER_OUT+
16	PortB_INDEX-	Channel_Index-	Analog_Index-	RESOLVER_OUT-

Table 8: J1 Port B Pin Assignments

### 7.9.3 J1 Hall Sensors

Pin (J1) Hall	Signal	Function
17	HALL A	Hall A Input
18	HALL B	Hall B Input
19	HALL C	Hall C Input

Table 9: J1 Hall Sensors Pin Assignments

### 7.9.4 J1 Power Pins

J1 Power Pin	Signal	Function
1	+11V	Encoder +11V supply <b>Note:</b> +11V is only available with Safe IO. For Regular IO this pin is not connected and must remain reserved.
2	+5VE	Encoder +5V supply
3	COMRET	Common Return
4	COMRET	Common Return
20	COMRET	Common Return



Pin Positions	Cable Connector
 <p>P-SOLWHI-V2-SAFE-008A</p>	 <p>P-SOLWHI-V2-SAFE-025A</p> <p>CLIK-MATE HOUSING FE 20PIN(2x10) P=1.5MM</p>

Table 10: Connector J1 Pin Positions and Cable Connector

## 7.10 Port C Connector Pinouts (J2)

For full details, refer to [section 13.2.6 Port C](#) in the [Platinum Safety Drive Manual](#).

The Port C connector includes the following functions:



Pin (J2)		Incremental Encoder	Absolute Serial Encoder	General Outputs
Signal		Function	Function	Function
1	COMRET	Common return		
2	PortC_A+	Channel A +	Absolute encoder clock+	General Output A+
3	+5VE	Encoder +5V supply		
4	PortC_A-	Channel A -	Absolute encoder clock-	General Output A-
5	+11V	Encoder 11V Supply <b>Note:</b> +11V is only available with Safe IO.		
6	PortC_B+	Channel B+	Absolute encoder data+	General Output B+
7	ANALOG1+	Analog Input		
8	PortC_B-	Channel B -	Absolute encoder data -	General Output B-
9	ANALOG1-	Analog Input complement		
10	PortC_Index+	Index+	Reserved	General Output Index+
11	COMRET	Common return		
12	PortC_Index-	Index -	Reserved	General Output Index-
Pin Positions			Cable Connector	
 <p>P-SOLWHI-V2-SAFE-009A</p>			 <p>P-SOLWHI-V2-SAFE-023A</p> <p>CLIK-MATE HOUSING FE 12PIN(2x6) P=1.5MM</p>	

Table 11: Port C Pin Assignments

## 7.11 Digital I/Os Connector Pinouts (J3)

The Safe IO Digital I/Os connector includes the following functions:

I/O: Refer to [Chapters 14 Safe Digital IO](#) and [15 Regular Digital IO](#) in the [Platinum Safety Drive Manual](#) for full details.

### 7.11.1 Safe IO: IO TYPE = K, L, N

The Digital I/Os connector includes the following functions:



Pin (J3)	Signal	IO TYPE K	IO TYPE L	IO TYPE N
1	VDD_RET	VDD Return		
2	IN1	Input		
3	VDD_24V	VDD 19.6V up to 30V	VDD 19.6V up to 30V	Not Used
4	IN2	Input		
5	OUT4	Output		
6	IN3	Input		
7	VDD_48V	Not Used	VDD 19.6V up to 60V	VDD 19.6V up to 60V
8	IN4	Input		
9	OUT7	Output		
10	OUT1	Output		
11	OUT8	Output		
12	OUT2	Output		
13	VDD_RET	VDD Return		
14	OUT3	Output		
Pin Positions			Cable Connector	
 <p>P-SOLWHI-V2-SAFE-010A-A</p>			 <p>P-SOLWHI-V2-SAFE-024A</p> <p>CLIK-MATE HOUSING FE 14PIN(2x7) P=1.5MM</p>	

Table 12: Safe IO Digital I/O Pin Assignments

### 7.11.2 Regular IO: IO TYPE = U, V

The Regular Digital I/Os connector includes the following functions:



Pin (J3)	Signal	TYPE U	TYPE V
1	VDD_RET	VDD Return	
2	IN1	Input	
3	VDD	4V to 30V	19.6V to 30V
4	IN2	Input	
5	IN6	Input	
6	IN3	Input	
7	SRC or SINK CONTROL	Not Used	<b>For Source:</b> 0 - Source Control <b>For Sink:</b> VDD
8	IN4	Input	
9	OUT7	Output	
10	OUT1	Output	
11	OUT8	Output	
12	OUT2	Output	
13	IN_COM	Digital Input Return	<b>For Source:</b> Digital Input Return <b>For Sink:</b> Digital Input Power
14	IN5	Input	
Pin Positions			Cable Connector
			 <p>P-SOLWHI-V2-SAFE-024A</p> <p>CLIK-MATE HOUSING FE 14PIN(2x7) P=1.5MM</p>

Table 13: Regular IO Digital I/O Pin Assignments

## 7.12 USB 2.0 Connector Pinouts (X3)

Refer to section 17.1 USB in the [Platinum Safety Drive Manual](#) for full details.

Pin (X3)	Signal	Function
A1	COMRET	Common return
A2	Not Connected	
A3	Not Connected	
A4	USB_VBUS	USB VBUS 5 V
A5	Not Connected	
A6	USBD+	USB _P line
A7	USBD-	USB _N line
A8	Not Connected	
A9	USB_VBUS	USB VBUS 5 V
A10	Not Connected	
A11	Not Connected	
A12	COMRET	Common return
B1	COMRET	Common return
B2	Not Connected	
B3	Not Connected	
B4	USB_VBUS	USB VBUS 5 V
B5	Not Connected	
B6	USBD+	USB _P line
B7	USBD-	USB _N line
B8	Not Connected	
B9	USB_VBUS	USB VBUS 5 V
B10	Not Connected	
B11	Not Connected	
B12	COMRET	Common return
	COMRET	Supply, Connector body



Pin Positions	
	 <p>USB TYPE C CABLE</p>

Table 14: USB Device Type C - Pin Assignments

## 7.13 RS-232 and Differential RS-232 (RS-422) Serial Communication(X4)

Refer to [section 17.3](#) and [17.4 RS-232/RS-422](#) in the [Platinum Safety Drive Manual](#) for full details.



**Important:**

In Network, for option T, do not connect CAN and RS-422 serial communication (Differential RS-232) together, connect either CAN or RS-422 serial communication (Differential RS-232).



**Note:** It should be noted that all signals are isolated and the Grounding denoted ISO\_GND throughout RS-232/RS-422 connections.

Pin (X4)	RS-232: Network: S		RS-422: Network: T	
	Signal	Function	Signal	Function
1	RS232_TX	RS-232 Level	RS422_TX+	Differential RS-232 Transmit Level
2	Not Connected		RS422_TX-	Differential RS-232 Transmit Level
3	RS232_RX	RS-232 Level	RS422_RX+	Differential RS-232 Receive Level
4	Not Connected		RS422_RX-	Differential R-S232 Receive Level
5	ISO_GND	Isolated Ground	ISO_GND	Isolated Ground
Pin Positions			Cable Connector	
			<p>P-SOLWHI-V2-NON-SAFE-215A</p> <p>Molex 501330-0500</p>	

Table 15: RS-232 and RS-422 Serial Communication (X4) Pin Assignments

## 7.14 EtherCAT IN Connector Pinouts (X1)

Fieldbus communications are industrial network protocols for real-time distributed control that allows connection of servo drives. The Platinum Solo Whistle supports the following EtherCAT fieldbus type industrial network protocol:

Fieldbus Type	Product Number
EtherCAT	PWHI-Sz-XXX/YYYFzz

Refer to section 17.2 EtherCAT/Ethernet in the [Platinum Safety Drive Manual](#) for full details.

Pin (X1)	Signal	Function
1	EtherCAT_IN_TX+	EtherCAT in
2	EtherCAT_IN_TX-	EtherCAT in
3	EtherCAT_IN_RX+	EtherCAT in
4	EtherCAT_IN_RX-	EtherCAT in
5	PE	Shield drain wire



Pin Positions	Cable Connector
 <p>P-SOLWHI-V2-SAFE-014A</p>	 <p>P-SOLWHI-V2-SAFE-022A</p> <p>CLIK-MATE HOUSING FE 5PIN(1x5) P=1.5MM</p>

Table 16: EtherCAT IN Pin Assignments

## 7.15 EtherCAT OUT/Ethernet Connector Pinouts (X2)

Refer to section 17.2 EtherCAT/Ethernet in the Platinum Safety Drive Manual for full details.

Pin (X2)	Signal	Function
1	EtherCAT_OUT_TX+/Ethernet_TX+	EtherCAT out/Ethernet transmit +
2	EtherCAT_OUT_TX-/Ethernet_TX-	EtherCAT out/Ethernet transmit -
3	EtherCAT_OUT_RX+/Ethernet_RX+	EtherCAT out/Ethernet receive +
4	EtherCAT_OUT_RX-/Ethernet_RX-	EtherCAT out/Ethernet receive -
5	PE	Shield drain wire



Pin Positions	Cable Connector
	 <p>P-SOLWHI-V2-SAFE-022A</p> <p>CLIK-MATE HOUSING FE 5PIN(1x5) P=1.5MM</p>

Table 17: EtherCAT OUT/Ethernet Pin Assignments

## 7.16 CAN Connector Pinouts (X1, X2) Safety Capability: O Only

Fieldbus communications are industrial network protocols for real-time distributed control that allows connection of servo drives. The Platinum Solo Whistle supports the following CAN fieldbus type industrial network protocol:

Fieldbus Type	Product Number
CAN	PWHI-SO-zXXX/YYYSzz
	PWHI-SO-zXXX/YYYYTzz



**Important:**

In Network for option T, do not connect CAN and RS-422 serial communication (Differential RS-232) together, connect either CAN or RS-422 serial communication (Differential RS-232).



**Note:** It should be noted that all signals are isolated and the Grounding denoted ISO\_GND throughout CAN connections.

The CAN Connector Pinouts (X1, X2) are as follows:

Pin (X1, X2)	Signal	Function
1	Not Connected	
2	ISO_GND	Isolated Ground
3	CAN_H	CAN_H bus line (dominant high)
4	CAN_L	CAN_L bus line (dominant low)
5	PE	Shield drain wire

Pin Positions	Cable Connector
<p>P-SOLWHI_CAN_V3-002A-A</p>	<p>P-SOLWHI-V2-SAFE-022A</p> <p>CLIK-MATE HOUSING FE 5PIN(1x5) P=1.5MM</p>

Table 18: CAN Connector Pin Assignments

## Chapter 8: Wiring


Once the product is mounted, you are ready to wire the device. Proper wiring, grounding, and shielding are essential for ensuring safe, immune and optimal servo performance of the drive.

The following table legend describes the wiring symbols detailed in all installation guides.

Wiring Symbol	Description
	Earth connection (PE)
	<b>User Side:</b> This symbol signifies that any type of grounding may be used on the user side
	VDD Return
	Isolated Ground
	Power Return
	COMRET Common at the Drive
	Shielded cable with drain wire. The drain wire is a non-insulated wire that is in direct contact with the braid (shielding). Shielded cable with drain wire significantly simplifies the wiring and earthing.
	Shielded cable braid only, without drain wire.
	Twisted-pair wires
	Encoder Earthing. The cable's shield is connected to the chassis (PE) in the connector. The servo drive shield is connected to Earth.

## 8.1 Wiring Connectors

### 8.1.1 Wiring Female CON CLIK-MATE Connectors



**Figure 7: Inserting a wire/pin to the Female CON CLIK-MATE Connector**

To insert a wire/pin to the female CON CLIK-MATE connectors do the following:

1. Select the relevantly colored wire to insert to a specific rectangular compartment on the female connector.
2. Use the appropriate Molex crimping plier (Molex P/N 63819-4600) to fasten a pin connector to the end of the wire.
3. Place the connector on a flat surface, in the orientation as shown in Figure 7. Notice that the rectangular slot has a niche at the bottom of the slot.
4. Insert the wire connector to the slot as shown in Figure 7. Make sure that the connector protrusion is inserted to the bottom of the rectangular slot.  
When inserting the wire connector to a slot in the second row, make sure to orientate the wire pin in the direction shown in Figure 7.
5. Repeat the same procedure for all other wire connections.

## 8.2 The Platinum Solo Whistle Connection Diagrams

### 8.2.1 EtherCAT with Safe IO (For Safety Capability F)




Figure 8: The Platinum Solo Whistle with Safe IO, Connection Diagram – EtherCAT

### 8.2.2 EtherCAT with Regular IO (Safety Capability: S, O)




Figure 9: The Platinum Solo Whistle without Safe IO, Connection Diagram – EtherCAT

### 8.2.3 CAN, RS-232, RS-422 (Safety Capability: O)




Figure 10: The Platinum Solo Whistle Connection Diagram – CAN

### 8.3 Motor Power (M1)

When connecting several drives to several similar motors, all should be wired in an identical manner. This will enable the same settings to run on all drives.




Figure 11: Brushless Motor and Brushed Motor Power Connection Diagram

#### To connect the motor power:

1. Ensure that the motor chassis is properly earthed.
2. Connect the appropriate wire from the Motor Power cables to the M1, M2, M3, and PE terminals on the Platinum Solo Whistle.

Make sure not to bundle the wires.

The phase connection is arbitrary, as Elmo Application Studio (EAS II) will establish the proper commutation automatically during setup. When tuning a number of drives, you can copy the setup file to the other drives and thus avoid tuning each drive separately. In this case, the motor-phase order must be the same as on the first drive.

3. For high EMI environment, it is highly recommended to use a 4-wire shielded (not twisted) cable for the motor connection. The gauge is determined by the actual RMS current consumption of the motor.

Connect the cable shield to the closest ground connection at the motor end.

For better EMI performance, the shield should be connected to Earth Connection (heat sink mounting holes).

## 8.4 Main (P1) and Control Power (P2)

The Platinum Solo Whistle receives power from Main and Control supplies and delivers power to the motor.

### 8.4.1 Main Supply

*Connect the DC power source cable to the VP+, PR, and PE terminals on the main power connector (P1).*

#### **To connect the main supply:**

1. The DC power supply source must be isolated from the Mains.
2. For best immunity, it is highly recommended to use shielded cables for the DC power source. A 3-wire shielded cable should be used. The gauge is determined by the actual current consumption of the motor.
3. Connect the cable shield to the closest earth connection near the power supply.
4. Connect the PE to the closest earth connection near the power supply.
5. Connect the PR to the closest earth connection near the power supply.
6. Before applying power, first verify the polarity of the connection.

### 8.4.2 Control Supply

*Connect the Control Power source cable to the VL+ and PR terminals on the Control Power connector (P2).*

#### **To connect to the control supply:**

1. The source of the control supply must be isolated from the Mains.
2. For safety reasons, connect the return (common) of the control supply source to the closest earth connection near the control supply source.
3. Connect the cable shield to the closest earth connection near the control supply source.
4. Before applying power, verify the polarity of the connection.

### 8.4.3 Dual Power Supply

Two DC power sources are required for the Platinum Solo Whistle, a DC power source, and a control supply for the logic:

- Main power isolated from the Mains
  - Main power 20 to 195V DC for 200V module
  - Main power 10 to 95V DC for 100V module
- Control Power: isolated DC source supply
  - Control Power where Safety Capability is F, S: Maximum 60V for the logic
  - Control Power where Safety Capability is O: Maximum 95V for the logic

The following figure describes the connection of main power and control.



**Important:**

**CAPACITANCE IN:** For Platinum Solo Whistle modules 20A/100V and 25A/100V a DC Bus Capacitance of 900uF must be connected between the VP+ and the PR as shown in the following figure. Alternative, the Elmo Tabla-200 (a DC Bus connection and capacitance bank) can be used. Please refer to the TABLA-200 Installation Guide.




Figure 12: Power Supply Connection Diagram



**Note:**

Make sure to connect the PR to the closest earth connection near the power supply.

### 8.4.4 Dual Power Supply for Safety Configuration

**Refer to the Chapter 10 Input Power Supply, in the Platinum Safety Drive Manual for details, specification, and connections.**

Two DC power sources are required for the Platinum Solo Whistle, a DC power source, and a control supply for the logic:

- Main power isolated from the Mains
  - Main power 20 to 195V DC for 200V module
  - Main power 10 to 95V DC for 100V module
- Control Power supply must be 12V to 60V (isolated from the Mains)

The following figure describes the connection of main power and control.



**Important:**

**CAPACITANCE IN:** For Platinum Solo Whistle modules 20A/100V and 25A/100V a DC Bus Capacitance of 900uF must be connected between the VP+ and the PR as shown in the following figure. Alternative, the Elmo Tabla-200 (a DC Bus connection and capacitance bank) can be used. Please refer to the TABLA-200 Installation Guide.




Figure 13: Power Supply Connection Diagram for Safety Configuration



**Note:**

Make sure to connect the PR to the closest earth connection near the power supply.

## 8.5 STO (Safe Torque Off) (J4)

**Refer to the Chapter 12 Safe Torque Off (STO) section, in the Platinum Safety Drive Manual for details, specification and connection of the STO.**

### 8.5.1 Source Mode – PLC Voltage Level

Refer to the diagram below for the PLC Source option connection.




Figure 14: STO Type Connection – PLC Source Option

### 8.5.2 TTL Mode – TTL Voltage Level

TTL option is available only for non-Safe IO. Refer to the diagrams below for TTL option connection.




Figure 15: STO Input Connection – TTL Option

## 8.6 Feedbacks (J1 and J2)

**Refer to the Chapter 13 Feedback, in the Platinum Safety Drive Manual for details, specification, and connections of the Feedback for safety.**

### 8.6.1 Feedback Port A

Port A supports the following sensor inputs:

- Incremental Encoder or absolute serial Encoder
- Differential pulse-width modulation (PWM) signal input
- Differential Pulse & Direction signal inputs

#### 8.6.1.1 Incremental Encoder




Figure 16: Port A Incremental Encoder Input – Recommended Connection Diagram



\* Note: If the Encoder supports 11V, then for Safety Capability F, 11V is available.

### 8.6.1.2 Absolute Serial Encoder

The following Absolute Encoder types are supported:

- EnDat 2.2
- Biss C and Biss B
- SSI
- Hiperface

The following is the diagram connection of the EnDat, Biss, SSI:




Figure 17: Absolute Serial Encoder – Recommended Connection Diagram for Endat, Biss, SSI



\* **Note:** If the Encoder supports 11V, then for Safety Capability F, 11V is available.

### 8.6.1.3 Hiperface

#### 8.6.1.3.1 Hiperface for Safety Application (Safety Capability “F”)

Hiperface with Safety Capability “F” - for Safe IO which includes a power supply of 11V.  
The following figure describes the connection diagram.




Figure 18: Absolute Serial Encoder – Recommended Connection Diagram for Hiperface – Safe IO

#### 8.6.1.3.2 Hiperface for Non Safety Application

Hiperface that requires power of 7-12V can be used with external power supply for non-safety application.  
The following figure describes the connection diagram.




Figure 19: Absolute Serial Encoder – Recommended Connection Diagram for Hiperface – Regular IO

### 8.6.2 Feedback Port B

Port B supports any of the following sensors:

- Incremental Encoder, interpolated analog Encoder or analog Hall sensors

Or

- Resolver (separate hardware option)

Differential PWM signal input can be connected to port B

#### 8.6.2.1 Incremental Encoder




Figure 20: Port B Incremental Encoder Input - Recommended Connection Diagram



\*Note:

If the Encoder supports 11V, then for Safety Capability F, 11V is available.

### 8.6.2.2 Interpolated Analog (Sine/Cosine) Encoder




Figure 21: Port B - Interpolated Analog Encoder Connection Diagram



\*Note: If the Encoder supports 11V, then for Safety Capability F, 11V is available.

### 8.6.2.3 Resolver




Figure 22: Port B – Resolver Connection Diagram

### 8.6.3 Feedback Port C

Port C provides:

- Incremental Encoder feedbacks
- Absolute Serial Encoder feedbacks
- Emulated Encoder output derived from port A, port B feedback inputs, or from internal variables

#### 8.6.3.1 Incremental Encoder

The following Incremental Encoder types are supported:




Figure 23: Port C Incremental Encoder Input – Recommended Connection Diagram



\*Note:

If the Encoder supports 11V, then for Safety Capability F, 11V is available.

### 8.6.3.2 Absolute Serial Encoder

Port C supports the following ABS feedback:

- EnDat 2.2
- Biss C and Biss B
- SSI
- Panasonic
- Tamagawa

The following is the diagram connection of the EnDat, Biss, SSI:




Figure 24: Absolute Serial Encoder – Recommended Connection Diagram for Endat, Biss, SSI, etc



**\*Note:** If the Encoder supports 11V, then for Safety Capability F, 11V is available.

The following is the feedback diagram connection for Panasonic, Tamgawai, Sanyo-Danki:




Figure 25: Absolute Serial Encoder – Recommended Connection Diagram for Panasonic, Tamgawai, Sanyo-Danki



**\*Note:** If the Encoder supports 11V, then for Safety Capability F, 11V is available.

### 8.6.3.3 Emulated Encoder Output




Figure 26: Emulated Encoder Differential Output – Recommended Connection Diagram



\*Note: If the Encoder supports 11V, then for Safety Capability F, 11V is available.

### 8.6.4 Feedback - Hall Sensors




Figure 27: Hall Sensors Connection Diagram



\*Note: If the Encoder supports 11V, then for Safety Capability F, 11V is available.

## 8.7 Safe Digital I/Os (Safe IO Type: K, L, N) (J3)

Refer to the Chapter 14 Safe Digital IO section, in the Platinum Safety Drive Manual for details, specification and connection of IO for Safety.

### 8.7.1 Digital Input with Test Pulse




Figure 28: Digital input with Test Pulse

### 8.7.2 OSSD Digital Input




Figure 29: OSSD Digital input

### 8.7.3 Digital Output

The Platinum servo drive provides three configurations of the VDD connection as shown in the Catalog Number :

- **K** — VDD=24V, All Outputs
- **L** — VDD=24V, Outputs 1,2,3,4 and VDD=48V, Outputs 7,8
- **N** — VDD=48V, Outputs 7,8

#### 8.7.3.1 Option K Configuration VDD\_24




Figure 30: Safe Digital Outputs for K Option Configuration

### 8.7.3.2 Option L Configuration VDD\_24 & VDD\_48




Figure 31: Safe Digital Outputs for Option L Configuration

### 8.7.3.3 Option N Configuration VDD\_48




Figure 32: Safe Digital Outputs for Option N Configuration

## 8.8 Regular Digital I/Os (Safe IO Type: U, V) (J3)

**Refer to the Chapter 15 Regular Digital IO section, in the Platinum Safety Drive Manual for specification details of the Regular IO connections.**

### 8.8.1 Digital Input and Output 5V Logic (IO Type: U)

The following figures describes the connections at the I/O Port for the Digital Input and Output TTL Mode.




Figure 33: Regular Digital Input 5V Logic Connection Diagram





Figure 34: Regular Digital Output Connection Diagram – 5V Logic Option

## 8.8.2 Digital IO PLC Source and Sink Mode (IO Type: V)


### 8.8.2.1 Digital Input and Output PLC Source Mode

The following figures describes the connections at the I/O Port for the Digital Input and Output PLC Mode.



P-SOLWHI-Ver.2-  
NON-SAFE-033F-A

Figure 35: Regular Digital Input Connection Diagram – PLC Source Option



P-SOLWHI-Ver.2-  
NON-SAFE-251C

Figure 36: Regular Digital Output Connection Diagram – PLC Source Option

### 8.8.2.2 Digital Input and Output PLC Sink Mode

The following figures describes the connections at the I/O Port for the Digital Input and Output PLC Sink Mode.




Figure 37: Regular Digital Input Connection Diagram – PLC Sink Option




Figure 38: Regular Digital Output Connection Diagram – PLC Sink Option

## 8.9 Analog Input

There is a single type of Analog Input in the Platinum Solo Whistle:

- Analog Input 1 – Differential  $\pm 10$  V

**Refer to the Chapter 16 Analog Input section, in the Platinum Safety Drive Manual for specification details of the Analog Input.**

### 8.9.1 Analog Input1 -Differential (J2)

The following circuit describes the internal interface of the Analog input.




Figure 39: Differential Analog Input

## 8.10 Communication

### 8.10.1 USB 2.0 (X3)

Use a standard USB 2.0 Type C cable and connector to connect the USB. Refer to section 17.1 in the [Platinum Safety Drive Manual](#).

### 8.10.2 Serial Communication (X4)

The X4 connector is optional for either RS-422 or RS-232 communication.

#### 8.10.2.1 RS-422 (Differential RS-232) Serial Communication

The following describes the RS-422 specification.

Specification	Details
Physical layer	Differential RS-232 Full duplex, serial communication
Interface	RS-422
Termination	120 Ohm It is required to connect termination of 120 ohm in the end of the TX signals (refer to the figure below)
Speed	Baud Rate of 0.0048 to 3.60 Mbps
Protocols	For setup and control

The following are RS-422 signals:

Signal	Function
RS-422_TX+	Differential RS-232 Transmit
RS-422_TX-	Differential RS-232 Transmit Complement
RS-422_RX+	Differential RS-232 Receive
RS-422_RX-	Differential RS-232 Receive Complement
ISO_GND	Isolated Ground




Figure 40: Differential RS-232 Communication Example

### 8.10.2.2 RS-232 Serial Communication




Figure 41: RS-232 Connection Diagram

### 8.10.3 EtherCAT (X1 and X2)



**Note:**  
The EtherCAT OUT port can be configured to an Ethernet Port

#### 8.10.3.1 EtherCAT Connection

The following drawing describes the EtherCAT communication, and the pinout drawing of the connector.

The Platinum Solo Whistle can serve as an EtherCAT slave device. For this purpose, it has two Ports X1 and X2, which are designated as EtherCAT In and EtherCAT Out.




Figure 42: EtherCAT optional Connection Schematic Diagram



**Note:**  
Always use CAT5e cables.

#### 8.10.3.2 EtherCAT Status Indicator




Figure 43: EtherCAT Status LED

The EtherCAT status indicator is a single red/green dual bi-colored LED that combines the green RUN indicator and the red ERROR indicator of the EtherCAT state machine. For further details, see the EtherCAT Application Manual.

### 8.10.3.3 EtherCAT Link Indicators

Each of the EtherCAT Ports has a LED; EtherCAT In and EtherCAT Out, which are shown in Figure 44.




Figure 44: Ethernet Link/Activity Connector LEDs

The green LEDs are the link/activity indicators. They show the state of the applicable physical link and the activity on that link; blinking green, both for the Link Act IN, and Link Act OUT.

### 8.10.3.4 EtherCAT Address Switches

The Platinum Solo Whistle has two rotary switches that allow the user to define a unique node ID to the slave. EtherCAT address switches set the ECAT address (LOW is ADD low, HIGH is ADD high). The two rotary switches offer up to 255 addresses, with the 0-setting referring to No alias address.

Figure 45 displays the switches available in the EtherCAT Version. Refer to section 17.2.5 EtherCAT Switches in the [Platinum Safety Drive Manual](#) for full details.




Figure 45: EtherCAT Address Switches


The positions of the switches on the drive are shown in Figure 45. Use a screwdriver to set the low and high bytes values of the drive EtherCAT address. This address is only retrieved after power-up.

## 8.11 CANopen (X1 and X2)



**Note:** It should be noted that all signals are isolated and the Grounding denoted ISO\_GND throughout CAN connections.

### 8.11.1 CAN Wiring



P-SOLWHI-Ver.2-  
NON-SAFE-256C

Figure 46: CAN Network Diagram – Drop Off Topology



**Caution:**

When installing CAN communication, ensure that each servo drive is allocated a unique ID. Otherwise, the CAN network may “hang”.

## Chapter 9: Powering Up

After the Platinum Solo Whistle is connected to its device, it is ready to be powered up.



### Caution:

Before applying power, ensure that the DC supply is within the specified range and that the proper plus-minus connections are in order.

### 9.1 Initializing the System

After the Platinum Solo Whistle has been connected and mounted, the system must be set up and initialized. This is accomplished using the *EASII*, Elmo's Windows-based software application. Install the application and then perform setup and initialization according to the directions in the *EASII User Manual*.

### 9.2 Heat Dissipation


The best way to dissipate heat from the Platinum Solo Whistle is to mount it so that its heat sink faces up. For best results leave approximately 10 mm of space between the Platinum Solo Whistle's heat sink and any other assembly.


#### 9.2.1 Thermal Data

- Heat dissipation capability ( $\theta$ ): Approximately 10 °C/W
- Thermal time constant: Approximately 240 seconds (thermal time constant means that the Solo Whistle will reach 2/3 of its final temperature after 4 minutes)
- Shut-off temperature: 86 °C to 88 °C (measured on the heat sink)

#### 9.2.2 Heat Dissipation Data

Heat Dissipation is shown in graphically below:





### 9.2.3 How to Use the Charts

The above charts indicate the net power conversion losses and exclude the control losses.

#### To determine if your application heat dissipation requires a heat sink:

1. Determine the power dissipation according to the "continuous current" and the DC bus voltage curve.
2. If the DC bus is not one of the two curves above, estimate the dissipation by interpolation. The estimation error is not critical.
3. The chart is calculated for continuous current operation. If the actual operation is pulsed current, add 25% to 30% to the power dissipation of the average (RMS) current.

When the Heat-Sink temperature reaches  $\approx 85^{\circ}\text{C}$ , the Platinum Solo Whistle will shut down.

Design the system for continuous operation so that the maximum Heat Sink temperature should be no higher than between  $80^{\circ}\text{C}$  to  $82^{\circ}\text{C}$ .

4. For model **PWHI-Sz-zXXX/YYYzzz**

If the average heat dissipation is less than  $\approx 4\text{W}$  to  $5\text{W}$  (Average operating power of  $300\text{W}$  to  $600\text{W}$ ) there will be no requirement for an additional external heat sink.

If the average Heat dissipation is higher than  $4\text{W}$  then an additional heat dissipation means is required, usually by connecting to an additional external heat-sink.

5. When an external Heat-Sink is required, calculate the thermal resistance of the heat sink according to:

$$\theta_{\text{C/W}} = \frac{80^{\circ}\text{C} - T_{\text{Ambient}}}{\text{Heat Dissipation}}$$

## Chapter 10: Dimensions

### 10.1 EtherCAT

#### 10.1.1 PWHI-SF-XXX/YYFz




Figure 47: Platinum Solo Whistle with Safe IO Board

#### 10.1.2 PWHI-SS-XXX/YYFz or PWHI-SO-XXX/YYFz




Figure 48: Platinum Solo Whistle

## 10.2 CAN

### 10.2.1 PWHI-SO-XXX/YYYSzz or PWHI-SO-XXX/YYYYTzz




Figure 49: Platinum Solo Whistle - CAN

*Go Safer, Smarter, Smaller, Simpler.*  
**Go Platinum.**

**Platinum**   
by **Elmo**

[www.elmocom.com](http://www.elmocom.com)